




# Asus Eee PC 1005HA RAM Replacement

Install new RAM in your Asus Eee PC 1005HA.

Written By: Mitchell Cesare



## INTRODUCTION

Use this guide to replace or upgrade RAM in the Asus Eee PC 1005HA.



### TOOLS:


- [Phillips #1 Screwdriver](#) (1)



### PARTS:


- [PC2-6400 2 GB RAM Chip](#) (1)

## Step 1 — RAM



- Loosen the captive screw in the RAM compartment cover.
- Remove the RAM compartment cover.
- ⓘ This photo shows the battery still attached, but it should be removed prior to removing or replacing the RAM.

## Step 2



- Pull the two RAM retaining arms away from the center of the RAM chip.
- Gently pull the RAM chip out of its socket.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 03:00:41 PM.